

ODR Inflatable Folding Instructions

If Bounce Houses are not returned clean and correctly folded, you will incur a \$50 cleaning fee




Step 1:

Ensure inflatable is clean, dry, and free of debris. Spread inflatable flat on ground with all zipper flaps and air tunnels open.


Step 2:

Fold side into middle.





Step 3:
Meet opposite side in the
middle.



Step 4:
Fold again in the middle,
ensuring air tunnels are open
to allow excess air to escape.



Step 5:
Tightly roll inflatable evenly
towards the open air tunnels to
remove excess air.

Step 6:
Wrap strap around the
inflatable ensuring air tunnels
are secure and pull tight.



If Bounce Houses are not returned clean and correctly folded, you will incur a \$50 cleaning fee